

Don't let frozen pipes  
disrupt your ministry ever again

PROTECTING  
THE GREATER  
GOOD™



As a valued customer, Church Mutual will provide you with a free water and temperature sensor kit and 24/7 monitoring – reserve yours today!

### EXPERIENCE PEACE OF MIND

What if you could be alerted 24/7 when temperatures got dangerously low or water was on the ministry floor? What if you did not have to be in the building to prevent damages and your busy day could go on as planned? What if peace of mind was free and easy to do?

Every year more than 1,000 Church Mutual customers experience damage and disruption to their ministries from frozen pipes, days lost in clean-up, administrative headaches, rescheduling, your ministry is put on hold.

Church Mutual has a free and easy solution to help prevent damages and disruptions before they can occur. Our temperature and water sensors are connected to a 24/7 monitoring alert system. Alerts are sent via text, email or phone to one or several contacts if temperatures are lower than normal or water is not where it should be.



### TAKE ACTION BEFORE DAMAGES OCCUR

- ▲ One customer is using the sensors after a frozen pipe burst and days were spent cleaning up. This year an alert will be sent before it gets too cold.
- ▲ Last year one customer prevented damage estimated at \$52,000 and was able to keep their doors open.
- ▲ The sensors let you know when temperature and water conditions are not right no matter where you are.

*Our customers' protection  
is our mission, so you  
have the peace of mind  
to focus on yours*

## TEMPERATURE & WATER SENSORS

### What's included

Depending on your facility, your system will include some or all of the following components:



#### GATEWAY

- ▲ Receives information from sensors and transmits data to monitoring and support center
- ▲ Must be plugged in (back-up battery)
- ▲ Dimensions: 5" x 3.5" x 1.5"



#### ROOM TEMPERATURE SENSOR

- ▲ Monitors temperature of a room
- ▲ Place in occupied area of a building in an inconspicuous location



#### PIPE TEMPERATURE SENSOR

- ▲ Monitors temperature of water pipes
- ▲ Place where pipes could be exposed to cold air



#### WATER SENSOR

- ▲ Monitors for presence of water in a chosen location
- ▲ Place where intrusion of water can occur like a basement or near a water heater

\* All Sensors are 3.5" x 2.5 by 1" and powered by batteries lasting 2-3 years.

**Installation is easy!** All you'll need is a crosshead screwdriver (No. 1 Phillips) and a cutting pliers or scissors.



See how it's done at <http://info.churchmutual.com/sensor-program-installation>

3000 Schuster Lane | P.O. Box 357 | Merrill, WI 54452-0357  
(800) 554-2642 | [info@churchmutual.com](mailto:info@churchmutual.com) | [www.churchmutual.com](http://www.churchmutual.com)



### Protection begins with three easy steps

1

Reserve your sensor at <http://info.churchmutual.com/sensor-program>

2

Install your sensors with the quick set-up guide provided.

3

Verify that your sensors are communicating with the 24/7 monitoring alert system.

Visit <http://info.churchmutual.com/sensor-program> to reserve your temperature and water sensors or to review our FAQ sheet on the program. The monitoring service is free for three years.

FOR ADDITIONAL INFORMATION  
PLEASE CONTACT YOUR SALES  
REPRESENTATIVE OR CALL CUSTOMER  
SERVICE AT (800) 554-2642, OPTION 1

PROTECTING  
THE GREATER  
GOOD

**Church  
Mutual**  
INSURANCE COMPANY